



No-Hub Coupling Installation Instructions

09/13rev



BRACING

To prevent movement, horizontal pipe and fittings 5" and larger should be suitably braced by the use of blocks, rodding or other suitable methods at every branch or change of direction.

TEST

For best results, testing of one floor (ten feet) at a time is recommended. If more than one floor at a time is tested, the system should be properly restrained; all bends, changes of direction and ends of runs should be restrained.

COUPLING MATERIAL

No-hub sealing sleeves (gaskets) are made of Neoprene conforming to ASTM C564. Chemical characteristics of Neoprene assure that the gasket will not decay or deteriorate from contact with effluents in the pipe, or chemicals in the soil or air around the pipe.

MATERIAL SPECIFICATONS

BANDS: Type 301 AISI Stainless Steel - Minimum tensile strength 165,000 psi.

SCREW HOUSING: Type 301 AISI Stainless Steel

SCREW: Type 305 AISI Stainless Steel, 5/16" hex head slant shoulder

SHIELD: Type 301 AISI Stainless Steel - Bright annealed; Rockwell B-85 minimum

SEALING SLEEVE (GASKET): High quality Neoprene elastomer compound, durometer 70+/- 5 per ASTM D2240



1. Loosen screws, separate shield and sleeve. Slip shield over one spigot.



2. Insert spigots into sleeve. Be sure that both spigots butt on center retainer inside sleeve.



3. Position shield over sleeve, tighten screws alternately to proper torque.



No-Hub Coupling Installation Instructions


09/13rev

BEFORE JOINING

1. Couplings should be installed with a calibrated torque wrench set at 60 inch pounds (1-1/2" - 10") or 80 inch pounds (12" & 15").
2. When using field-cut pipe, the ends should be cut square.


JOINING PROCEDURE

1. Install the Neoprene sealing sleeve on one end of the pipe or fitting to be joined.
2. Place the stainless steel shield over the other end to be joined.
3. Insert both ends into the sealing sleeve until they butt against the molded center stop, inside the sealing sleeve.
4. Center the shield over the sealing sleeve and tighten as directed below.




1-1/2", 2", 3", 4" Sizes

- A. Tighten bands alternately to 60 inch pounds torque




5", 6" 8", 10" Sizes

- A. Tighten bands 2 and 3 alternately to 60 inch pounds torque
- B. Then bands 1 and 4 alternately to 60 inch pounds torque



12" & 15" Sizes

- A. Tighten bands 3 and 4 alternately to 80 inch pounds torque
- B. Tighten bands 2 and 5 alternately to 80 inch pounds of torque
- C. Tighten bands 1 and 6 alternately to 80 inch pounds of torque



MIN-MAX SITUATIONS

- A. First torque the minimum side 3-2-1 and 3-2-1 again
- B. Then torque the maximum side 4-5-6 and 4-5-6 again
- C. Finally, torque 2-1 and 4-5 to 80 inch pounds

ALL HORIZONTAL PIPE AND FITTINGS, 5" AND LARGER, SHOULD BE BRACED TO PREVENT MOVEMENT AT EVERY BRANCH OR CHANGE OF DIRECTION